


# Z-SUITE




## Z-SUITE USER MANUAL

ENTER AN ENVIRONMENT OF  
PROFESSIONAL 3D PRINTING

## DOWNLOADING Z-SUITE

# Z-SUITE


Download the latest version of Z-Suite from [www.zortrax.com](http://www.zortrax.com). You will need a serial number of your printer to complete the download



## ADDING MODEL


# Z-SUITE

Click + icon or use drag and drop option to upload a .stl model



## ADDING MODEL


# Z-SUITE



Select a model in .stl file format and click OPEN

## ADDING MODEL

# Z-SUITE




Model is added to workspace. Left click to select or deselect the model

Save your model at any time

## ROTATING WORKSPACE VIEW


# Z-SUITE



Select this icon to rotate workspace view

## ROTATING WORKSPACE VIEW


# Z-SUITE



Left click and move your mouse to rotate workspace view

## MOVING WORKSPACE VIEW

# Z-SUITE




Select this icon to move workspace view



## MOVING WORKSPACE VIEW


# Z-SUITE



Left click and move your mouse to rotate workspace view

## SELECTING WORKSPACE VIEW


# Z-SUITE



Click this icon to quickly select one of four standard views

## ROTATING MODEL

# Z-SUITE




With this option you can rotate a model in the workspace in three directions

You can rotate model by adding angle or clicking and dragging the selected model. Choose one of the axis: X, Y or Z to select in which direction you want to rotate a model

## MOVING MODEL


# Z-SUITE



Click this icon to move model in workspace. You can move model by editing X and Y parameters or click and drag selected model

## RESIZING MODEL

# Z-SUITE




Click this icon to scale the model

You can resize model by changing parameters in the table or by using click and drag option

## COPYING & DELETING MODEL

# Z-SUITE




If you want to delete model, select it and click this icon or press delete key on your keyboard

When color turns red it means that your model is outside the workspace. Resize or move model to fit the workspace


To copy a model select an object and press CTRL + C keys

## AUTO ARRANGING MODEL

# Z-SUITE



Click this icon to auto arrange your models in the workspace




If your model is ready to print  
click PRINT




# PRINTING

# Z-SUITE

Select the PRINTING PROFILE (filament type), LAYER THICKNESS, SPEED, INFILL, SUPPORT ANGLE, COOLING SPEED



Click ADVANCED to enable additional printing options



SURFACE LAYERS function helps to choose the amount of layers at the top and at the bottom to achieve thicker finishing of the model


AVOID HOLES function gives you ability to eliminate the blobs from the model surface. We recommend you to enable that option

OFFSET function helps to correct the internal and external dimensions of a model

Click PREPARE TO PRINT to start generating zcode file

# PRINTING

# Z-SUITE




Click YES to display zcode

STOP

SAVE PROJECT

# PRINTING


# Z-SUITE



Z-SUITE will show you estimated print time and filament usage

# PRINTING


# Z-SUITE



This is 3D print preview of the actual deposition of layers

# PRINTING

# Z-SUITE




PAUSE function allows to pause the printing process to change the filament color and divide it into stages\*. This option also allows you to preview layers

- SAVE TO SD-CARD
- SAVE AS...
- BACK TO MODEL

# PRINTING

# Z-SUITE



You can insert pause marks to divide the printing process into stages

Choose SAVE TO SD CARD, SAVE AS or BACK TO MODEL

**zortrax**  
ideas turned into shapes

[www.zortrax.com](http://www.zortrax.com) // [www.zortrax.pl](http://www.zortrax.pl)